


Penetration Depth Factor Calculation

$D_p = 3.4 (S - 0.276)$

Penetration
Depth Factor
 D_p - (Inches)



Object Sensitivity - S (Inches)