## ROOF LOAD ZONE MAP

| | |
|---|---|
| North | 40 PSF (Snow) |
| Middle | 30 PSF (Snow) |
| South | 20 PSF (Minimum) |